

# EVACUATOR

Site Alarms

## Evacuator Synergy + Call Point & Auto Detector Basic Instructions

Evacuator Synergy + Alert System Specification and user operating instructions.

Thank you for choosing the Evacuator Synergy + Wireless Alert system. In order for you to realise the full potential and reliability of this Category One Wireless system it is vitally important that you read this user manual in **full** before attempting to use the system. Failure to understand the correct installation method and functions of the system may lead to intermittent and unreliable connectivity.

We would be delighted to assist all Evacuator Alarm clients with free Telephone Support during normal office hours. For assistance please contact our Technical Support Team on 0330 135 5337 or alternatively email us on [technical@evacuatorialarms.com](mailto:technical@evacuatorialarms.com)

### Specification Overview (All models)

Battery Powered Wireless connected Call Points & Auto Detectors. Complete wireless operation connected via Wireless Connection. Can be connected to other Synergy + devices in the range.



# EVACUATOR


## Site Alarms

### Fitting the Antenna

The antenna should now be fitted to the Silver TNC docking point located on the top of the unit. The Antenna should be placed over the TNC connector and twisted in clockwise motion until it locates into place. Test that it has been located correctly by gently pulling on the Antenna in an outwards motion.

### Connecting Power Supply

Connect the power pack into the port on the pcb as highlighted below. Now secure the battery pack into the backplate using the provided Velcro strap.



### Pairing to a Base Station


To pair to a Base Station press Buttons B & C together for 1 second and then release both B & C (yellow & red LED's will illuminate), now follow instructions on Base Station Screen. For pairing without a Base Station please contact our helpline on 0330 135 5337

Please follow our YouTube video to assist with pairing your Devices to a Base Station, QR Code provided below



### Silencing System

To Silence the system using a Call Point press buttons A & B together, the initiating device will continue to sound until reset with the provided key. Silencing from a Auto Detector may be more impractical due to being ceiling mounted. Silencing of the system may also be performed directly from the Base Station



# **EVACUATOR**

*Site Alarms*

## **Evacuator 12 Month Limited Warranty**

All products manufactured by FMC (Firstmark Consultancy Limited), carry a 12-month warranty. This is a return to base warranty which includes manufacturing faults and defects, but does NOT include accidental damage, neglect, inappropriate use, any modification, or failure to follow instruction as to the, Storage, Installation, Commissioning, use or Maintenance of the goods, or (if there are none) reasonable and sensible good trade practice.

Goods returned to base that are deemed to be faulty, will, at our discretion, either be replaced, credited or repaired

All goods supplied by FMC are intended to be supplied to and used by persons within trade and business ONLY, and therefore warranties are not transferable to members of the public.

## **Pairing without a Base Station**

Please follow our YouTube video to assist with pairing your Devices to a Base Station, QR Code provided below

